

Fitting a Mag Spacer for 9mm Basepad

1. Disassemble magazine and set parts to the side.



2. Insert the mag spacer all the way to the top of the mag tube with radiused edge facing the back of the mag tube.

Note: You may use a steel or plastic mag spacer. The steel mag spacer will not have a radiused edge.



3. Holding the mag spacer in place, insert the follower and mag spring into the mag tube and tight against the feed lips.



4. With a sharp pencil, draw a line on the mag spacer flush with the bottom of the mag tube.
5. Remove mag spacer. Using a knife, cut along the line you previously drew to remove excess.
6. Reinsert the mag spacer (as stated in Step 2). Reinsert the follower and mag spring (as stated in Step 3). Place the DP basepad over the bottom of the magazine.
7. The DP basepad will hold the mag spacer in place.

Note: Standard spacers that already fit to STI factory basepads are too short for the DP tool-less basepads.