



Figure 1

180-220 Grit Sandpaper.



Figure 2



Figure 3

Some Glock and Para followers will catch the inside of the basepad as it transitions from the magazine tube to the BP Basepad. If you fail to get the capacity, the DP Basepad typically adds. You will have to radius the follower as shown in the picture. You can use a fine file or 180-220 grit sandpaper. It only takes a few seconds and will allow the follower to smoothly transition into the DP Basepad.