

THUMB REST INSTALLATION

1. Position Thumb Rest so slide can be removed.
2. With Rest in place, mark holes with scribe through holes.
3. Drill with #36 drill, then tap with 6-32. Tap screw in place.

***BE SURE SCREWS DO NOT STICK THROUGH SCOPE MOUNT AND RUB THE SLIDE.**